


Electrical Component Location

TIRE PRESSURE MONITORING SYSTEM (DIAGNOSTICS)

3. Electrical Component Location

A: LOCATION




TPM00037


(1) Tire pressure monitoring control module

(2) Tire pressure warning light


(3) Transmitter 1 — 4



TPM00038



TPM00018



TPM00004

SUBARU.